

HYDRAULIC SYMBOLS

RQRM*-P*/*/I/A

RQAM*-P*/*/I/A

RQRM*-P*/*/A

RQAM*-P*/*/A


RQ*M*-P

UNLOADING VALVE WITH AUTOMATIC OR SOLENOID OPERATED VENTING (FOR CIRCUITS WITH ACCUMULATOR) SERIES 51

> RORM*-P FOR REMOTE PILOTING ROAM*-P WITH INCORPORATED CHECK VALVE


SUBPLATE MOUNTING

OPERATING PRINCIPLE




The RQ*M*-P valves have not only the normal function of relief valves or safety valves but also the characteristic of freely discharging the pump flow either when the set pressure value is reached, or when the solenoid valve is de-energized. In order to assure this condition, the use of an accumulator that guarantees pressure in the circuit is required. The use of a check valve prevents the accumulator from discharging through the valve in the open position.

 They are made with a balanced shutter main stage that has wide passages for large flows, with reduced pressure drops.



NOTE: for the solenoid valve DS3 characteristics see catalogue 41 150


1 - IDENTIFICATION CODE




2 - CHARACTERISTIC CURVES

(values obtained with viscosity of 36 cSt at 50°C)

ADJUSTMENT p [bar] RQRM3 RQ*M5 RQ*M7 400 RQ*M*-P6 300 RQ*M*-P5 200 100 RQ*M*-P3 0 0 100 200 300 400 500 Q [l/min] p [%] RQ*M/1 RQ*M2 100 90





3 - HYDRAULIC FLUIDS

0

100

200

0

Use mineral oil-based hydraulic fluids HL or HM type, according to ISO 6743-4. For these fluids, use NBR seals (code N). For fluids HFDR type (phosphate esters) use FPM seals (code V). For the use of other kinds of fluid such as HFA, HFB, HFC, please consult our technical department.

300

400


Using fluids at temperatures higher than 80 °C causes a faster degradation of the fluid and of the seals characteristics.

The fluid must be preserved in its physical and chemical characteristics.


500 Q [l/min]

RQ*M*-P SERIES 51

4 - RQRM3-P OVERALL AND MOUNTING DIMENSIONS




5 - RQRM5-P AND RQRM7-P OVERALL AND MOUNTING DIMENSIONS



21 420/117 ED

RQ*M*-P SERIES 51

6 - RQAM5-P AND RQAM7-P OVERALL AND MOUNTING DIMENSIONS



7 - ADJUSTMENT KNOB

The RQ*M*-P valves can be equipped with a SICBLOC adjustment knob. To operate it, push and rotate at the same time. To request this option, add: /M (see paragraph 1).

8 - ELECTRIC CONNECTORS

The solenoid valves are never supplied with connectors. Connectors must be ordered separately, please see catalogue 49 000.

9 - MANUAL OVERRIDE, BOOT PROTECTED: CM

Whenever the solenoid valve installation may involve exposure to atmospheric agents or utilization in tropical climates, use of the manual override, boot protected is recommended. Add the suffix CM to request this device (see paragraph 1).

For overall dimensions see catalogue 41 150.

10 - SUBPLATES

(see catalogue 51 000)

	RQRM3-P	RQRM5-P	RQRM7-P	RQAM5-P	RQAM7-P
Туре	PMRQ3-AI4G rear ports	PMRQ5-AI5G rear ports	PMRQ7-AI7G rear ports	PMRQA5-AI5G rear ports	PMRQA7-AI7G rear ports
P, T, U ports dimensions	P: 1/2" BSP T: 3/4" BSP	1" BSP	1" 1/4 BSP	3/4" BSP	1" 1/4 BSP
X port dimensions	1/4" BSP	1/4" BSP	1/4" BSP	-	-



DUPLOMATIC MS Spa

via Mario Re Depaolini, 24 | 20015 Parabiago (MI) | Italy T +39 0331 895111 | E vendite.ita@duplomatic.com | sales.exp@duplomatic.com duplomaticmotionsolutions.com